


New 300/500/800 Bosch Dishwasher Installation - Overview

New Improvements for faster, safer, and more secure Installations












New Bosch Dishwasher Installation – Guidance with POP


Important Information


Route the hoses through the left or right hand side traps. Refer installation guide for details.

L'information importante

Conduisez les tuyaux par la bande de côté gauche ou droit. Référez-vous le guide d'installation pour des details.







Factory applied installation pop will be included on the back of the new units






Free 'Quick-Install Kit' included:

- 1. Pre-connected braided water inlet hose
- 2. Pre-connected drain hose
- 3. Flexible connection for hard wiring*
- * When installing to an outlet connection, a 3-prong power cord is available for purchase (#SMZPC002UC).

New Bosch Dishwasher Electrical Installation Options




Bosch dishwashers (300,500, 800, 800 Plus* series) now have a new electrical installation process.

A proprietary connector to plug into the dishwasher in the rear.

Option #1 Hardwire

- •Power cord with junction box included with appliance.
- •This installation type is valid for ~70 % of installations in North America.






Supplied with appliance

Option #2 Electrical receptacle - plug

- •The Bosch three prong Power Cord Kit SMZPC002UC is the power cord for easy and compliant connection to electrical receptacle. (Only UL listed cord for the 300, 500 800 series dishwashers)
- •Accessory should be stocked and readily available for purchase to avoid any improper installation applications which could void the manufacturers warranty.






Home Appliances





Installation Option #1 Hardwire

Hardwire Electrical supply conductors shall be a minimum #14 AWG copper wire rated at 167°F or higher

Connect wires to junction box terminal block and securely tighten the terminal block screws. Plug the end of the supply cord into the back of the dishwasher as shown until it clicks.










The dishwasher is designed for an electrical supply of 120V, 60 Hz, AC, connected to a dishwasher-dedicated, properly grounded electrical circuit with a fuse or breaker rated for 15 amps.



Installation Option #2 Connection to a Receptacle & Benefits







SMZPC002UC MAP \$19 - 47 Dishwasher 3-Prong Power Cord Kit (rear connection)

- (300/500/800/800 Plus* Series)
- •The water supply line is already included so the customer does not need to purchase one, which is the most expensive connection component for the installation.
- •Our power cord is a high quality cord containing larger gauge of wire which cannot be found at big box supply stores.
- •Benefits to builders to ensure safe approved connections.
- •Using this cord, limits improper install by eliminating the human element of manually wiring the appliance.
- •Units should be stocked at the store level as well as available on installation trucks

*800 plus models, SH_9PT are already supplied with power cord, no additional accessory required.



Bosch Dishwasher Ascenta Installation

Ascenta Models Only:



SGZPC001UC MAP \$18 - 61" Dishwasher 3-Prong Power Cord

- •Current and new Ascenta models utilize this cord.
- Power cord is to be wired directly to the dishwasher