

# The next generation of Bosch dishwashers.

Now the industry's most advanced clean meets the ultimate dry.\*



#### The deepest clean with PowerControl<sup>™</sup>.\*

**PrecisionWash® technology** is featured on every Bosch dishwasher and uses intelligent sensors to assess soil levels and scan progress throughout your cycle.

**PowerControl™ spray arm** enhances **PrecisionWash®** performance by allowing you to select which areas get a targeted clean-no matter where you load your dishes on the bottom rack. So even your most challenging dishes get the deepest clean.





## Three energy efficient and advanced drying technologies.

**PureDry**<sup>®</sup> is our core drying system that does not pull in outside air. And with no exposed heating element, you can safely place plastics anywhere, even on the bottom rack, without fear they will warp or melt.

**AutoAir**<sup>®</sup> automatically opens the door at the end of the drying cycle allowing moisture to escape and fresh air to circulate for even drier dishes.



#### Ultra sleek and streamlined exteriors.

All-new modern designs with sleek door handles, streamlined touch control panels, and anti-fingerprint stainless steel on all series.\*\*

\* PowerControl™ on 800 Series and Benchmark models only. \*\* Excludes ADA-compliant and German-made models. **CrystalDry™** technology transforms moisture into heat up to 176° F, to give dishes, including plastics, the ultimate dry.

1 1	( Houlence: Smart Cycle
	What items are you loading in your dishwaster? Select at Prime & Books Wencent Grink Andrea was why to to statisticity and Grink Andrea was why tho statisticity and grink Andrea was why to statisticity and prime was an and the statisticity and prime was an and the statisticity and prime was and the statisticity and the statisticity and the prime was and the statisticity and the statisticity and the prime was and the statisticity and the statisticity and the prime was and the statisticity and the statisticity and the prime was and the statisticity and the statisticity and the prime was and the statisticity and the statisticity and the prime was and the statisticity and the statisticity and the prime was and the statisticity and the statisticity and the prime was and the statisticity and the statisticity and the prime was an and the statistic type was and the statisticity and the prime was and the statisticity and the statisticity and the statisticity and the prime was and the statisticity and the statis
CONNECTED BY Home Connect	e Carlo even excelence of an organital e Carlo even of an extension or ar or ar Dort show a gain

## Clean smarter, not harder-only with Wi-Fi enabled Home Connect<sup>®</sup>

Enhance your cleaning experience with personalized app features like Smart Cycle which provides intelligent cycle guidance for the best results every time. Or get hands-free voice control with Amazon Alexa or Google Home and so much more, all when you use Wi-Fi-enabled Home Connect<sup>®</sup>.

### **Bosch Dishwasher Quick Tips and Tricks**







## Other useful tips to get the most from your Bosch dishwasher:


- With Bosch PrecisionWash®, there is no need to pre-rinse—simply scrape food off and place dishes in the dishwasher.
- Set your water heater temperature between 120 and 125 degrees F. If too high, the soap will not activate and perform properly.
- **Start your dishwasher** by pressing the "On/Off" button and selecting a cycle and option if desired, and then press "Start". Always ensure nothing is blocking the spray arms before starting a wash cycle.
- All Bosch dishwashers use PureDry<sup>®</sup>, with no exposed heating element for energy-efficient drying that is safe on plastics. PureDry<sup>®</sup> whisks moisture away from dishes as they cool, so you may see condensation on the tub walls, which is normal.
- **Clean dishwasher surfaces** with a damp cloth and mild soap. Do not use abrasives or bleach-based cleaners.


For complete product information, refer to the Use and Care Manual available online at: www.bosch-home.com/us/owner-support





**BOSCH** 





Note: German-made dishwashers have a slight height difference (3/16") while fitting into a standard 24" cutout

BOSCH

